

## **USE & CARE INSTRUCTIONS**





READ AND SAVE THESE INSTRUCTIONS RPICTURE FOR REFERENCE ONLY

SAFETY INFORMATION	01
PACKING LIST	03
PRODUCT OPERATION INSTRUCTION	04
FILTER REPLACEMENT	05
	07

# SAFETY INFORMATION

### WARNINGS

This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

-This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

-Children shall not play with the appliance.

- -Cleaning and user maintenance shall not be made by children without supervision.
- · Read all instructions before using the product.
- · To avoid fire or shock hazard, plug the appliance directly into a Right electrical outlet.
- · To avoid fire or shock hazard, DO NOT pull, bend, distort and damage the power cord.
- · DO NOT use the product if the power cord/power plug/power outlet is damaged.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use the product near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- · DO NOT touch the power cord with wet hands.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or when ever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- · NEVER drop or insert any object into any openings.
- · DO NOT cover cord with throw rugs, runners, or similar coverings.
- · DO NOT use outdoors.
- · DO NOT place anything on top of the unit.
- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT use gasoline, beneze, thinner, harsh cleaners, etc, on and/or in the unit while cleaning as they will damage the product. **NEVER** use alcohol or other solvents.
- WARNING TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS FAN WITH ANY SOLID-STATE SPEED CONTROL DEVICE.

## SAFETY INFORMATION

### FOR USAGE

- ·DO NOT use the machine without filter in.
- · DO NOT place the machine near heat sources such as heater, radiators, stoves and so on.
- To ensure the effect of purification, keep the air purifier around with a certain area to let wind go in and out. Do not clean and reuse the composite filter; Please be careful when cleaning the machine. A strong corrosive
- Only soft cloth can be used to clean the surface of the machine, otherwise the machine may be damaged or broken, and may cause sensor failure.
- It is forbidden to wipe with alcohol or organic solvent, otherwise it will damage the product or cause electric shock, fire, etc.
- When cleaning the machine or not using this machine, please disconnect the device power supply and wipe the dust or other matter of the power plug and power plug. Otherwise, it may cause electric shock or fire caused by short circuit.


### FOR USAGE

- · Please install the equipment in a dry environment.
- · Do not install the equipment in a flammable environment.
- · Please take out the polybag outside before installing the machine.

#### Warm Reminder


- This machine is not suitable for people with disabilities, perceptual impairment, mental retardation or children.
- It is prohibited to sit, lean on or climb onto the equipment to prevent the machine from being unstable and causing injury.
- $\cdot$  When moving, be sure to stop running and pull out the power plug.
- $\cdot$  DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit.
- Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- If the equipment produces odors at running time, please stop using the equipment and contact after-sales to replace the odor net.
- The cord, wires and/or cables supplied with this product contain chemicals, including lead or lead compounds, know to the state of California to cause cancer and birth defects or other reproductive harm. Wash hands after using.





# PRODUCT OPERATION INSTRUCTION

### CONTROL PANEL



04

On power on state, the device enters in standby mode when ON/OFF indicator light turns red



Press "ON/OFF" button to turn on/off the device. (The indicator of running function turns green when power is on)



Press "SLEEP" button to turn on/off sleep mode.

- a. On sleep mode, only "SLEEP" indication button turns green.
- b. Press any button to turn down sleep mode.



On power on state, press "CHILD LOCK" for 3 seconds to turn on child lock mode, the indicator light turns green.

- a. On Child lock state, press the button for 3 seconds to turn down the child lock mode, the indicator light turns white.
- b. All the other buttons are not working when child lock is on.



Please replace the filter when the filter indicator"FILTER"light flashes and make sounds. (please refer to the instruction for how to replace the filter) a. Press "FILTER"button for 3 seconds to reset the filter life



#### Press the "SPEED" button to adjust the fan speed when power is on

- a. The fan speeds switches from High to Medium to Low to Medium by each touch. And the indicator light turns green.
- b. Medium speed is default set when turns on the unit.
- c. " ( )" indicates fan speed. It changes via fan speed.

# FILTER REPLACEMENT

1. Turn it off and unplug the unit

### NOTICE

Please pull out the power lord to cut off the power supply. The device is still under stand by mode when touching "ON/OFF" button only.

2. Remove the bottom cover


Please rotate the bottom cover according to the arrow instruction way to remove it.

3. Please take out the combination filter and pack it into polybag to avoid dust falling indoor.


### NOTICE

- a. To ensure the purifying efficiency, please read the instruction of filter replacement.
- b. Please do not reuse the filter which has reached its working life. the instruction of filter replacement.









## FILTER REPLACEMENT

4. (Method 1) Put a towel or other soft protective pad on the desktop, turn the main unit upside down, and place the filter element on the bottom. Then install the bottom cover, and rotate it according to the arrow way and lock it well. After the installation, flip the main unit and the top faces up.

(Method 2) Adjust the direction of the new filter, install the filter well, put the main unit and rotate the bottom cover according to the arrow way at bottom until it is locked.

------

5. When the unit is powered on, press "ON/OFF" button to turn on the unit. Then press the "FILTER" button for 3 seconds to reset the filter time.

### NOTICE

The working life of filter may differ from the different using environmnt. It can be simply judged by smell or sound generated by the working unit.



# TROUBLESHOOTING GUIDE

If malfunction occurs in the air purifier, please check as blow phenomenon showed before repair

Phenomenon	Possible reason	Solution
Machine can not start	A. Unplug power plug. B. Machine rear cover not in position.	<ul><li>A . Reconnect power plug.</li><li>B. Re-install the rear cover in position.</li></ul>
Odor in the outlet	<ul><li>A. More pollutants indoor such as more smoking.</li><li>B. Filter is polluted severely.</li></ul>	<ul><li>A. It is recommended that the room air be changed.</li><li>B. Replace with the all new filter.</li></ul>
None obvious dust removal effect,none air quality improvement	<ul> <li>A. Filter is not installed into the machine.</li> <li>B. Machine is placed in narrow space or space with obstacles nearby which may have negative impact on the purification effect.</li> <li>C. Filter is too dirty.</li> </ul>	<ul><li>A. Install the filter correctly.</li><li>B. Place the unit at least a foot away from the obstacles.</li><li>C. Replace for new combination filter.</li></ul>
Running noise loud	A. Whether the installation is not tight. B. Other matter stored in the machine.	A.Contact after-sales center. B.Clean other matters.
Main buttons not work	LOCK mode is worked.	Press 3 second to turn off the LOCK mode.
Filter cannot be installed	Filter is installed opposite.	Adjust the filter to right directionand install the filter to the bottom slot.



After all the checks above, troubleshooting still existed, please contact our service center or contact technical service center. Do not attempt to disassemble and maintain themaintenance by yourself, to avoid any danger and damages to the machine.